



किंग जार्ज चिकित्सा विश्वविद्यालय उ०प्र०, लखनऊ- 226003
निर्माण विभाग (सिविल सेक्शन)

फोन (कुलसचिव कार्यालय) : 0522-2257540 फैक्स : 0522-2257539 वेबसाइट : www.kgmcindia.edu.

पत्रांक: 2778/M10

दिनांक: 17/10/17

QUOTATION NOTICE

To,

M/s.....

.....

.....

The sealed quotation are invited for Water proofing treatment for C.I traps and joints of C.I pipe for toilet of F-Block & IIIrd floor, IVth floor and Vth floor in Gautam Budh Hostel KGMU as given below. Interested parties may submit their quotations to the undersigned duly marked on the envelope the number and date of this notice latest by 3.30p.m on dated 24/10/17

Sl.No.	Particulars	Qty	Unit	Rate
1	<p>N-TRAP JOINT –Series of steps Involved in the Process are as follows:-</p> <ul style="list-style-type: none">• Tile is removed or dismantled• Then area under work is uncovered and cleaned by unstable or volatile chemical• Cleaned area is repaired by filling/honeycomb covering and chemical putty then treated with 1st layer of ISO 117CR.• Then 1ft or 1.5ft pipe is set as per the required height and level.• After pipe is set 2nd Layer of ISO117CR is applied for its covering. <p>After this work is done Tile and drain/jali is fixed and is ready to use after 24 hours.</p>	20 N-trap joint	Each	
2	<p>C,I PIPE JOINT:- Series of steps involved in the process are as follow:-</p> <ul style="list-style-type: none">• Grinding is done on area of work and then it is cleaned.• Cleaned area is scratched and leaked joint is covered with 2" web covering.• Then around 3mm thick chemical putty is applied.• 1st Layer of ISO117CR is applied for its covering• 4" web covering is done and 2nd layer of ISO 117CR is applied.	35C.I pipe joint	Each	
3	<p>P/S TRAP JOINT:- Series with Orissa pan sheet & European sheet of steps involved in the process are as follows:-</p> <ul style="list-style-type: none">• Commode is removed or dismantled• Then area under work is cut (1'x1') and uncovered around 6" to 1'5" and cleaned by unstable or volatile chemical.• Cleaned area is repaired by filling/honeycomb covering and chemical putty then treated with 1st layer of ISO 117CR.• Then 4" pipe is set as per the required height & IVI• After pipe is set 2nd layer of ISO 117CR is applied for its covering. <p>After this work is done Tile and commode is fixed and is ready to use after 24 hours.</p>	12P/s trap	Each	

Term & Condition

- 1 The rates quoted should be inclusive all taxes as applicable and are FOR at site.
- 2 The work will be completed within given time.
- 3 Quantity can be increase or decrease as per requirements.

Yours faithfully

Sunil Kumar
Assistant Engineer